






C 130





HRM500-1




HRM500-2







HRM500-3



HRM500-4



HRM500-5



C130

Item	Part No	Description	Qty
1	C130-0011	Deck cover weldment	1
2	C130-0012	Front cover weldment	1
3	C130-0013	rear cover weldment	1
4	C130-0111	clamp plate	1
5	C130-0110	rubber flap	1
6	C130-0102	fender rod	1
7	GB879.1-2000	pin 4*20	2
8	GB97.1-85	washer12	31
9	GB97.1-85	wahser 10	54
10	GB97.1-85	wahser 14	1
11	C130-0101	fender	13
12	GB5783-86	Bolts M10*25	10
13	GB5783-86	BOLTS m10*30	17
14	GB5783-86	Bolts m12*35	12
15	GB5783-86	Bolts M14*40	1
16	DIN985-87	Nut M10	33
17	DIN985-87	NUT M12	37
18	DIN985-87	NUT M14	1
19	C130-0015	Roller	1
20	C130-0114	Roller bearing supplort	2
21	EFN120-0012	bearing UC205	2
22	GB70.3-2000	Bolts M*25	8
23	GB70.3-2000	Bolts M12*35	4
24	GB70.3-2000	Bolts M10*30	6
25	C130-0014	Blade rotor	2
26	C130-0017	Bearing seat	1
27	C130-0113	bearing seat	1
28	GB894.1-86	circle 50	2
29	GB894.1-86	Circle 90	2
30	GB9877.1-88	Oil seal FB-85*60*10	2
31	GB276-94	Beairg 6210	2
32	C130-0106	blade	52
33	C60-0105	blade support	26
34	GB5782-86	Bolts M12*80	27
35	GB93-87	spring washer12	6
36	GB93-87	spring washer 14	4
37	0356500q	Hydraulic motor	1
38	GB6170-86	Nut M14	4
39	GB899-88 A	BOLTS m14*38	4
40	C130-0016	motor protect cover	1
41	GB1152-89	oil cup M6	1
42	HRM500-0017	hanging plate	1
43	C130-0103	skid wedlment	2
44	C130-0116	hammer	1

HRM500-1

Item	Part No	Description	Qty
1	C130-0018	Oil hose from motor	2
2	1CG9-30-12OG	adapter	3
3	C130-0019	Oil hose to Motor	1
4	GB3541-83	link Bolts	1
5	JBT / 982-1977	washer 14	2
6	0356500q	hydraulic motor	1
7	1CB-16-04WD	fitting	1
8	LSQ-S6-02SF	plug	1
9	LSQ-S6-02PF	plug	1
10	HRM500-0075	Oil hose to Motor	1
11	HRM500-0065	oil hose from valve	2
12	HRM500-0060	oil hose on arm	2
13	JB / T 982-1977	washer27	2
14	LSQ-S6-06SF	plug	2
15	LSQ-S6-06PF	plug	2
16	GB5782-86	boltsM8*50	2
17	GB93-87	sparing washe8	16
18	QH TT-G3	clamp plate	2
19	QH TTPG-322	pipe clamp	2
20	GB96.2-2002	washer 8	13
21	GB5783-86	boltsm8*16	13
22	HRM500-0123	oil hose cover	1
23	HRM500-0014	arm weldment	1
24	DIN985-87	mut M24	1
25	HRM500-0104	pin 40	1
26	GB879.1-2000	pin 10*55	1
27	HRM500-0017	hanging frame	1
28	GB879.1-2000	pin 10*40	13
29	HRM500-0111	pin	3
30	GB1152-89	oil cup M6	4
31	HRM500-0016	push rod	1
32	HRM500-0015	swing arm	2
33	HRM500-0053	oil cylinder	1
34	HRM500-0108	pin	2
35	HRM500-0066	oilhose	2

HRM500-2

Item	Part No	Description	Qty
1	HRM500-0107	pin	1
2	HRM500-0103	pin40	4
3	HRM500-0012	swivel	1
4	GB879.1-2000	pin12*70	4
5	GB12613-90	axle sleeve P45*40*40	8
6	DIN985-87	nut M12	6
7	GB97.1-85	washer12	11
8	HRM500-0023	limited block	1
9	GB5782-86	bolts M8*65	3
10	GB93-87	spring washer8	16
11	QH TT-G5	clamp plate	3
12	QH TTPG-535	pipe clamp	3
13	HRM500-0068	oil hose	2
14	HRM500-0051	cylinder	1
15	HRM500-0106	pin	1
16	HRM500-0013	boom wedlement	1
17	GB5783-86	bolts M8*16	13
18	GB96.2-2002	washer8	13
19	HRM500-0122	OIL HOSE COVER	1
20	HRM500-0067	OIL HOSE	2
21	GB879.1-2000	PIN 10*40	13
22	HRM500-0108	PIN	2
23	HRM500-0052	CYLINDE	1
24	HRM500-0109	PIN	1

HRM500-3

Item	Part No	Description	Qty
1	GB5783-86	boltsM6*20	3
2	GB96.2-2002	washer 6	3
3	GB93-87	spring washe 8	16
4	GB5783-86	bolts M8*16	13
5	GB96.2-2002	washer 8	13
6	GB97.1-85	washer 6	7
7	DIN985-87	nut M6	3
8	HRM500-0018	oil tank	1
9	HRM500-0121	fender	1
10	GB5783-86	bolts M10*25	8
11	GB97.1-85	washer 10	16
12	DIN985-87	Nut M10	7
13	HRM500-0019	oil tnak cover	1
14	WG-0004	Manual box	1
15	JB7941.3-1995	Oil leveler	1
16	HRM500-0022	support foot	2
17	WG-0006	square pin	2
18	HRM500-0102	pin	2
19	HRM500-0101	pin	1
20	TY-SXZJ-12	lock pin	3
21	HRM500-0021	valve fix frame	1
22	BDL-L100E-YW	valve	1
23	HRM500-0020	cable	1
24	GB12613-90	axles sleeve	8
25	HRM500-0040	valve	1
26	HRM500-0103	pin	4
27	DIN985-87	nut M36	4
28	GB879.1-2000	pin 10*40	13
29	GB879.1-2000	pin 12*70	4
30	HRM500-0105	pin	2

HRM500-4

Item	Part No	Description	Qty
1	GB5783-86	bolts M6*12	4
2	GB93-87	Spring washer	4
3	GB97.1-85	washer 6	7
4	BHM225-0121	oil tank cover	1
5	BHM225-0120	rubber washer	1
6	JB / T 982-1977	washer 17	4
7	WG-0003	plug screw	1
8	RFA-160×30L	oil filter	1
9	JB / T 982-1977	washe 48	1
10	HRM500-0119	adapter	1
11	HRM500-0073	oil hose	1
12	1CM-18WD	fitting	1
13	HRM500-0074	oil hose	1
14	DIN985-87	nut M8	3
15	GB5782-86	bolts M10*80	2
16	GB5782-86	Bolts M8*60	3
17	1CB-18-06WD	fitting	3
18	1CG9-30-12OG	adapter	3
19	HRM500-0011	base frame	1
20	HRM500-0072	oil hose	1
21	HRM500-0071	oil hose	1
22	HRM500-0069	oil hose	1
23	2C9-16W	adpater	1
24	1CM-16-18WD	fitting	2
25	DIN985-87	nut m10	7
26	GB5783-86	bolts M12*30	5
27	GB879.1-2000	pin 10*40	13
28	HRM500-0105	pin	2
29	CC-16W	adapter	1
30	HRM500-0054	cylinder	1
31	1CB-16-06WD	fitting	5
32	BHSM225-0157	fitting	2
33	1CM-16-18WD	fitting	2
34	ND-0.75L / 210	energy accumulator	1

HRM500-5

Item	Part No	Description	Qty
1	GB5783-86	Bolts M 10*25	8
2	GB97.1-85	WASHER10	16
3	FM120.00.401	PTO COVER	1
4	GB5783-86	BOLTS M8*16	13
5	GB96.2-2002	washer8	13
6	HRM500-0010	gear box	1
7	3-2ADPF60-12DL17P261	gear pump	1
8	GB70.1-2000	bolts ,10*45	4
9	GB97.1-85	washer 10	16
10	HRM500-0063	oil hose	1
11	1CB-30-12WD	fitting	4
12	1CB-18-06WD	fitting	3
13	HRM500-0064	oil hose	1
14	GB5783-86	bolts M12*30	5
15	1CB-16-06WD	fiting	5
16	BHSM225-0157	fiting	2
17	JB / T 982-1977	wahse17	4
18	HRM500-0114	adapter	1
19	HRM500-0113	clamp cover	1
20	GB70.1-2000	bolts ,8*250	6
21	DN32	valve	1
22	GB3452.1-82	o ring	1
23	HRM500-0115	adapter	1
24	CLAMP22-38	clamp	1
25	HRM500-0117	adapter	1
26	HRM500-0116	clamp cover	1
27	DN15	valve	1
28	GB3452.1-82	o ring	1
29	HRM500-0118	adapter	1
30	卡箍16-25	clamp	1
31	1CG-18-08	fitting	1
32	1CB-36-16WD	fitting	1
33	HRM500-0062	oil hose	1
34	HRM500-0061	oil hose	1