




Main Assembly Views

Model #SD-95



Sub-Assembly Parts Breakdown

Model #SD-95




Key	Part No.	Description	Qty.
1	A	Main Frame Asembly	1
2	B	Lower Axle Assembly	1
3	C	Hopper Assembly	1

Complete Hopper Assembly Parts Breakdown




Model #SD-95


1



2




3



Hopper Assembly Parts Breakdown


Model #SD-95



Key	Part No.	Description	Qty.
1	D 5020	Clear Cover	1
2	D 5008	Screen	1
3	D 5000	Hopper	1


Complete Axle Assembly Parts Breakdown

Model #SD-95



Complete Lower Axle Assembly Parts Breakdown


Model #SD-95



Key	Part No.	Description	Qty.
1	D 5904	Wheel	2
2	D 5022	5/16-18 x 3/4 Carriage Bolt SS	4
3	D 5003	Bearing Bracket	2
4	D 5023	5/16 Kepts Nut SS	4
5	D 5014	Clamp Cleat	4
6	D 5021	1/4-20 x 3/4 Carriage Bolt SS	8
7	D 5942	1/4-20 Hex Nut SS	8
8	D 6134	1/4" Lock Washer SS	8
9	D 5009	Adjustment Angle	1
10	D 5919	3/16 x 2" SS Cotter Pin	2
11	D 5001	Agitator Bar	2
12	D 5923	Axle Bushing	2
13	D 5005	Slide Gate	1
14	D 5010	Stop Angle	1
15	D 5006	Calibration Cam	1


Main Frame Assembly Parts Breakdown

Model #SD-95



Main Frame Assembly Breakdown

Model #SD-95



Key	Part No.	Description	Qty.
1	D 5011	Operator Lever	1
2	D 5921	3/16 x 1-1/4 Spring Pin	1
3	D 5917	Handle Grip	2
4	D 5908	Handle Assembly	1
5	D 5907	1/4-20 x 1-3/8 HHSS	2
6	D 6134	1/4 Lock Washer	2
7	D 5942	1/4-20 Hex Nut SS	2
8	D 5002	Main Frame	1
9	D 5004	Actuator Rod	1